

?? Cables and power supplies in general

https://www.astroshop.eu/telescope-accessories/cables-power-supplies/15_97

- [Handling lithium-ion batteries](#)

?? Handling lithium-ion batteries

DANGER! Lithium-ion cells can get hot or ignite and cause serious injury when exposed to extreme conditions.

Do not connect the positive and negative poles of the battery with metal objects (e.g. wire).

Only use approved LiFePO₄ chargers

Be especially careful while wearing necklaces, rings, bracelets, hairpins, or other metal objects.

Do not puncture, hit, or step on the battery.

Do not immerse the battery in liquid and avoid moisture.

Do not use a LiFePO₄ battery with other types of batteries.

Do not connect the battery to an alternator or non-electronically controlled charging system (except when using a voltage regulator).

Do not smoke next to the battery.

Be careful not to let heavy objects fall on the battery.

Keep it away from children.

Do not store it in or in the near fire, on stoves or on other Places with high temperatures.

Do not expose it to direct sunlight or use/store the battery in cars in hot weather. Otherwise, the battery may release heat or ignite. This use may also result in loss of performance and shortened lifespan.

Do not disassemble or modify the battery. The battery is equipped with safety and protection devices that, if damaged, could cause the battery to become hot, explode or ignite.

Stop using the battery immediately if it emits an unusual odor, becomes hot, changes color or shape, or otherwise appears unusual during use, charging, or storage.

Do not insert the battery into Microwave oven, a high pressure container or on induction hotplates.

Check it regularly for damage, cracks and corrosion on the connections. Do not use it if you notice any damage.

The terminals can always be live, so do not place metal objects on a Li-ion battery.

Avoid short circuits, deep discharges and high charging currents.

Use tools with insulated handles.

When working with the battery, avoid wearing any metal objects, e.g. watches, bracelets, rings, etc.

If the battery burns, you must use a Type D foam or CO2 fire extinguisher to extinguish it.

Do not open or disassemble the battery. Electrolyte is highly corrosive. Under normal conditions contact with it is impossible. If the case is damaged, do not touch exposed electrolyte or powder as it is corrosive.

Li-ion batteries can become projectiles in an accident due to their large mass. Always ensure secure attachment

Transport it carefully as Li-ion batteries are sensitive to mechanical shock.

Before use, check whether the battery emits noises that indicate a defect. Do not use the battery if it crackles, hisses or anything similar Sounds can be heard – there is a risk of fire.

Use good quality and correct size cables. Battery cables must be crimped, preferably soldered. Solder connections alone are not sufficient. UL listed battery cables are recommended.

General safety instructions

Please keep this guide safe so you can refer to it. Pass it on to subsequent owners.

This device is not intended to be used by persons (including children) with reduced physical, sensory or mental capabilities or who lack experience and/or knowledge, unless they are supervised or given instructions by a person responsible for their safety, how to use the device.

The device is not a toy for children. Therefore, keep children away from it. Children must be supervised so that they do not play with the battery.

Converting or changing the device impairs product safety. Changes and repairs to the device may only be carried out by the manufacturer or by persons expressly authorized by the manufacturer. Never open the device yourself. Don't do any repairs yourself!

Handle the device carefully. It can be damaged by shocks, blows or falls from even a small height.

Keep the device away from moisture and extreme heat.

Stay nearby while charging the battery and check its temperature regularly. If the heat is high, stop charging immediately. A battery that heats up or deforms during charging must not be used.

Never immerse the device in water or other liquids. Do not touch the device with wet or damp hands.

Check the device for damage before using it for the first time. Do not use it if there is visible damage.

Never use the device after a malfunction, e.g. if it has been dropped into water, dropped or otherwise damaged.

Disconnect the battery from connected devices if you will not be using it for a long period of time.

Disposal instructions for batteries

Batteries must not be disposed of in household waste. As a consumer, you are legally obliged to return defective batteries that can no longer be charged for proper disposal. You can hand in your batteries at public collection points in your community and wherever batteries of the same type are sold.

Electrical devices contain valuable resources, but also pollutants. The collection points give them to certified waste disposal companies who check whether the devices can be reused. Ideally, old devices can be refurbished. If not, pollutants are removed from the devices and valuable resources are recycled if necessary. This protects the environment.

Note on waste avoidance

According to Directive 2008/98/EC on waste and the legislation of the Member States of the European Union, waste prevention measures generally have priority over waste management measures. In order to avoid waste, the main aim of electrical and electronic devices is to extend their service life by repairing defective devices and selling functional used devices instead of disposing of them. The federal waste prevention program contains further information.